



- Verify bolt circle diameter and anchor bolt projection.
- Use anchor bolt template to assure accuracy.
- Drill holes in plywood and use as a locator for anchor bolts.

DRILLED TOP	
<b>ANCHOR BOLT KIT: BOLT4/11</b> with 18.75" anchor bolts fits these RAB poles PS4-11-10D2 PS4-11-15D2 PS4-11-20D2 PS4-11-25D2	<b>ANCHOR BOLT KIT: BOLT4/7</b> with 30" anchor bolts fits these RAB poles PS4-07-20D2 CS-15D PS4-07-25D2 CS-20D PS4-07-30D2 CS-25D
<b>BASE COVER KIT: BCK-S4 (for electrician)</b> (1) 2pc steel base cover, bronze (4) 1/4" - 20 black base cover screws (1) 4" pole cap CAT# PCAP4 (for use with drilled poles) <b>FIBERGLASS POLES BASE COVER: BCK-CP-S</b>	

TENON TOP	
<b>ANCHOR BOLT KIT: BOLT4/11</b> with 18.75" anchor bolts fits these RAB poles PS4-11-10WT PS4-11-15WT PS4-11-20WT PS4-11-25WT	<b>ANCHOR BOLT KIT: BOLT4/7</b> with 30" anchor bolts fits these RAB poles PS4-07-20WT CS-15WT PS4-07-25WT CS-20WT PS4-07-30WT CS-25WT
<b>BASE COVER: BC4 (no cap)</b> <b>FIBERGLASS POLES BASE COVER: BCK-CP-S</b>	

**NOTES:**

- Hand hole covers are attached to pole
- RAB drilled (non-tenon) poles come pre-drilled for 2 area lights at 180°
- Additional fixture mounting holes may be drilled in the field.



Must be printed on 11x17" paper at 100%.